




User Manual



ADVANTAGE AIR®

Quick Start	3
HOME	4
SIMPLE TIMER	4
AIR CON	5
ZONES	6
PROGRAMS	6
HELP	11
SETTINGS.....	12
MyZone™ - (optional feature)	15
Constant Zones	17
Android Tablet	18
Smart Phone – Quick Setup Guide	18
Network Troubleshooting	23
Troubleshooting.....	26
Service Records.....	27

Quick Start

This section will give you a brief description about each of the buttons found on the home screen.

- **ON/OFF:** The large power button at the centre top of your home screen allows you to turn your system ON or OFF, Yellow is ON & Black is OFF.
- **SIMPLE TIMER:** The simple timer function is used to turn your air conditioning system ON or OFF after 30min, 1 hour or 2 hours.
- **AIR CON:** Allows you to change your Target Temperature, Mode & Fan Speed.
- **ZONES:** Allows you to turn zones ON/OFF and increase or decrease the airflow. If your system has optional Integrated Temperature Control (ITC) sensors installed, you can also choose zone temperature set-points for each zone.
- **PROGRAMS:** Complete advanced 24/7 scheduling, which allows you to program up to 5 different schedules, allowing you to nominate which zones you would like on, which days of the week you would like the program to run & what times it should run.
- **SETTINGS:** Allows you to change text colour, background colour, screen brightness, turn the screen beep on/off, or rename zones.

HOME

Upon first power up, the system will take up to 3 minutes to initialise.

If you walk away from your screen it will go to sleep, to wake the screen simply press the button on the left hand side of the screen.

The AIR CON STATUS window conveniently displays information about your air conditioner's status right on the home screen.

Your home screen will look like this, easy to read & intuitive, the large power button is used to turn your Air Conditioner ON or OFF.



HANDY HINT: To move between HOME, AIRCON & ZONES simply swipe left or right.

SIMPLE TIMER


The MyAir4 system features a SIMPLE TIMER which you can use to have your air conditioning system turn ON or OFF after 30minutes, 1 hour or 2 hours.

Note: This is a once-only time that does not repeat each day. More advanced programmes can be set using the PROGRAMS menu.

AIR CON

Press the AIR CON button to change the following:

- AIR CON ON/OFF;
- MODE allows you to change between HEAT, COOL, FAN ONLY & DRY;
- FAN SPEED can be used to change your indoor fan between LOW, MED, HIGH & AUTO settings; and
- TARGET TEMPERATURE will be used to set the system temperature set-point, however, in systems with MyZone™ functionality this setting is not required.



Pressing BACK on any screen will take you back to the home screen.

Note: Setting very low temperatures on COOL mode, or very high temperatures on HEAT mode will not cool or heat your zones any faster, but will cause your air-conditioner to run for longer to attempt to achieve the target temperature. This will result in higher energy usage.

Some unit models may not have AUTO or DRY functionality.

ZONES

Press ZONES to bring up the Zones Screen:



Pressing a zone name toggles that zone between ON and OFF. The zone turns Blue for ON, and Black for OFF.


There can be two different types of zones in MyAir4 depending on whether your system has optional Integrated Temperature Control (zones with temperature sensors).

- **Temperature Zone:** If your zone has a temperature sensor installed, MyAir4 will allow you to choose your desired temperature with the - / + buttons. MyAir4 will aim to maintain the desired temperature in that zone by automatically controlling airflow while the air conditioner is running.
- **Airflow Zone:** If there is no sensor installed in your zone then it will be shown as an AIRFLOW zone. In this instance, you have the ability to control the air in 5% increments. Use the - / + buttons when a zone is turned ON, to adjust the amount of airflow going to that zone.

HANDY HINT: Save energy by switching off zones you are not using.


PROGRAMS

Press PROGRAMS to bring up the Programs Screen:



The **PROGRAMS LIST** screen features a dark blue background. At the top left is a light blue **BACK** button. The title **PROGRAMS LIST** is centered at the top. Below the title, a light blue bar displays **PROGRAM 1**, the time **11:00 AM - 04:00 PM**, and the days **MON, TUE, WED, THU, FRI**. To the right of this bar are **RENAME** and **DELETE** buttons. At the bottom right is a light blue **ADD NEW PROGRAM** button. At the bottom, a white text box contains the instruction: "Enables you to set a time to start and stop the air conditioning provided to each zone. Click an existing program to edit."

To add a program press **ADD NEW PROGRAM** which will bring you to the following screen:



The **PROGRAM - SET START AND STOP TIMES** screen has a dark blue background. At the top left is a light blue **BACK** button. The title **PROGRAM - SET START AND STOP TIMES** is centered at the top. Below the title is a navigation bar with **TIMES** (highlighted in red), **DAYS**, **ZONES**, and **SAVE**. Below the navigation bar, a white text box says: "Scroll up or down to set the time to start and stop the air conditioning." Below this are two sections: **START** and **STOP**. Each section has three selection wheels. The **START** wheels show 11, 45, 12, 00, AM, and 1, 15, PM. The **STOP** wheels show 1, 45, 2, 00, AM, and 3, 15, PM. At the bottom left, it says "Running time: 2hrs." At the bottom right, it says "Selected Times?" next to an orange **CONTINUE** button.

To enter the Start time for the program to swipe the selection wheel up or down, the wheels will stop slowly after the swipe.

To enter the Stop time for the program swipe using the **STOP** selection wheel.

Press **NEXT** to continue to the following screen:

BACK PROGRAM - SET DAYS

TIMES DAYS ZONES SAVE

Set which days the program will run.

SELECT DAYS

MON TUE WED THU FRI SAT SUN

OFF OFF OFF OFF OFF OFF OFF

Selected Days? **CONTINUE**

Select the days for the program to run.

Press NEXT to continue to the ZONE selection screen:

BACK PROGRAM - SELECT ZONES AND SAVE

TIMES DAYS ZONES SAVE

KITCHEN OPEN DINING OPEN

LOUNGE OPEN THEATRE OPEN

STUDY OPEN MASTER BED OPEN

FIONAS ROOM OPEN ADAMS ROOM OPEN

STUARTS ROOM OPEN GAMES ROOM OPEN

Select which zones are open for the program

Selected Zones? **SAVE**

Select the zones you would like ON during the program, when finished press SAVE to return to the PROGRAMS LIST.


Note: Your system will start in its current MODE eg If the system was last used for COOLING the program will start in that mode. A zone selected as ON during a program will default to its last percentage air volume setting or temperature setting if you have ITC sensors.

Rename/Delete Programs

On the programs main screen, press RENAME next to the program you wish to change; to remove a program press DELETE.



Select the zone you would like to rename & you will be presented with a keyboard.



Press CLEAR to wipe the program name, OR:

Press the BACKSPACE key to delete only some of the characters

Enter new program name using the on-screen keyboard

Program names can be up to 12 characters in length, when finished, press SAVE

Disable Programs

This feature is handy to use when going away on holidays and provides a quick and easy way to ensure you save energy by ensuring the air-conditioner does not run when you're not at home.

To disable a program you can press the program you wish to edit from the PROGRAM LIST & deselect all of the days, this will leave your PROGRAM in place but it will not run.

BACK **PROGRAM - SET DAYS**

TIMES **DAYS** ZONES SAVE

Set which days the program will run.

SELECT DAYS

MON **TUE** **WED** **THU** **FRI** **SAT** **SUN**

OFF OFF OFF OFF OFF OFF OFF

Selected Days? **CONTINUE**

To re-enable the program go into the relevant program as described previously & select the days which you want it to run.

HELP

On the ZONES page, press the HELP button to show the HELP Screen this will show the difference between Temperature Zones & Airflow Zones. It also explains that zones marked with a yellow C are your constant zones & these may open or close independently to balance your system.

BACK **ZONES HELP**

Temperature Control Zone: Airflow Control Zone:


THEATRE - 24°C + **STUDY** - 90% +

Press on the zone name to open or close the zone.

Press + to increase the Temperature or Airflow to the zone.


Press - to decrease the Temperature or Airflow to the zone.

To rename a zone press Settings then press the Rename Zones button.

Zones marked with the  logo are constant zones. These are set by the installer and may open independently to balance your system.

SETTINGS

On the home screen, press SETTINGS to display the following screen:



Text Colour

Press this button to cycle through the 3 text colour options.

Background Colour

Press this button to cycle through the 12 background colour options.

Screen Beep

Choose SCREEN BEEP IS ON or SCREEN BEEP IS OFF depending on your preference.

Screen Brightness


To adjust screen brightness press the – or + buttons.

Rename Zones

Press this button to change the zone names. You will be presented with a list of all your zones.



Select the zone you would like to rename.



The cursor will default to the end of the zone name.

Press CLEAR to clear all characters, OR:

Press the DEL key to delete only some of the characters

Enter new characters using the on-screen keyboard

Zone names can be up to 12 characters in length,

when finished, press DONE.

System Information

On the SETTINGS page, the top right hand box displays any warnings such as low battery warnings for your temperature sensors, your installer may have also provided their contact number here so it's always on hand when it comes time for your annual service. It will also display any warnings or error codes for your air conditioning unit.

Close App


Pressing this button allows you to exit the MyAir4 app to use other android apps on your touch screen, see page 17 for further information.

Tech Setup

This button is used by your air conditioning professional to set up your system on the day of installation.

MyZone™ - (optional feature)

In a standard temperature controlled zone, the temperature sensor simply manages airflow to the room while the machine is running; in the MyZone your air-conditioner unit will respond to the temperature in this specific zone to decide when it should start, stop or ramp up / down while maintaining a constant airflow in the zone. MyZone must be a temperature controlled zone.



The MyZone can be identified easily as the colour of the zone will change to a DARK BLUE & display the °M symbol. In the example above you can see the KITCHEN is currently the active MyZone.


This feature can be particularly important when you have an unusually high requirement for air conditioning in a particular area. For example, if you invited a group of people over to watch a movie and you are all sitting in the theatre with the electronic equipment on, you will have a larger requirement for air conditioning than in other rooms in the house. Setting the theatre as MyZone will ensure that the system continues running until the temperature set-point for *that* room is achieved.

Only one temperature controlled zone can be the MyZone at any one time, if you are using multiple zones it is suggested you make the largest zone the MyZone. To change a MyZone press & hold the zone name of the zone you wish to nominate.

If you have this feature enabled you will see the °M HELP in your ZONES screen as pictured below.



Press **°M HELP** to see the following screen which explains the functionality of the MyZone.



NOTE: MyZone is an optional feature available on systems where MyZone has been enabled, your dealer may enable this feature depending on the way you use your system & the layout of the installation (see quick start guide page 4-5). MyZone™ is not available if your MyAir4 is installed with a Mitsubishi Electric air conditioning unit.

Constant Zones


Your MyAir4 system may be set up with electronic Constant Zones. These are pre-programmed zones that open up to relieve excess air pressure in your air-conditioning system if insufficient zones are open. Constant Zones are noted with a small letter c next to the air volume percentage of that zone.

If you have the MyZone feature enabled the zone selected as the MyZone will automatically take over as a constant, airflow will be constant in this zone & the temperature controlled by your air conditioner increasing/decreasing it's capacity.

Android Tablet



In order to use your phones and tablets to control your system, you will need to connect the Android touch screen controller to your home Wi-Fi network.

First, exit the MyAir4 app. To do this, press the SETTINGS button then select CLOSE APP, you will be presented with the following screen



Press RUN OTHER APPS & you will then see the main Android home screen, from here you can connect to a Wi-Fi network to access the Google Play Store & download other apps etc.

If you are not familiar with the Android operating system an abundance of information can be found on the internet, however, here are the steps required to connect your system to your Wi-Fi router.

1. After selecting RUN OTHER APPS, press the apps icon on the right. 
2. Then press the settings icon.
3. At the top of the list turn on the Wi-Fi on and then select your network access point (home Wi-Fi network) from the list on the right, or if your router has WPS you can use the WPS icon in the top right corner  and follow the prompts.
4. If your home Wi-Fi router does not have WPS, you can select your home Wi-Fi network then input your home Wi-Fi password & press Connect.

Smart Phone – Quick Setup Guide


Homeowner Instructions:

1. You will need to have a Wi-Fi network in your home. In order to connect to the network, you will need to know what it is called, and have the password handy.
Note: Your network does not require an internet connection for your MyAir4 app to control the air conditioning system.
2. Connect your smart device (tablet/phone) to your home Wi-Fi network. You may need to enter your network password; some routers have the network name (SSID) & password printed on a sticker located on the reverse of the router.
3. Ensure you have downloaded the **MyAir4** app on your device, see subsequent sections for detailed instruction on installing the Apple or Android app to your device.
4. Once the air-conditioning system is installed, you will need to connect the Android touch screen controller to the Wi-Fi network using the password details for your Wi-Fi network, combined with the instructions on the previous page.
5. Once the Android touch screen controller is connected to the same network as your smart phone / tablet, run the MyAir4 app on your handheld device. It should automatically connect and display the correct information for your air conditioning system.

Apple Devices

(Works on: iPhone 3GS and later | All iPad's | iPod Touch 4 and later)

1. If you do not have an Apple ID and password, then create one and verify your email by checking and following the instructions in the email from Apple.
 - a. See instructions here: <http://support.apple.com/kb/ht2534>
 - b. Be sure to set your country as Australia.
2. Download the MyAir4 App from the Apple App Store.
 - a. Using your iPhone/iPod/iPad - click on the App Store icon.
 - b. Click on the Search tab.
 - c. Type "MyAir4" into the search box.
 - d. Press Search.
 - e. Select the correct MyAir4 App by Advantage Air (It's Free).




- f. To install, press the blue FREE button, and then Green INSTALL button.
- g. Enter your Apple ID password (it's case sensitive).

Apple Installation Troubleshooting


1. Is your device an iPhone 3 or older? If so, Apple no longer support these devices and our App cannot be downloaded to your device. Requirements: Compatible with iPhone, iPod touch and iPad. Requires iOS 4.3 or later. (iPhone 3GS or later).
2. If you are using an iPad you will need to select the iPhone apps button at the top of the search results screen.

If your device does not fall into the above categories, you should have no problem downloading the App to your device.


Android Devices


To start downloading items on the  Google Play Store app, you need to add a Google Account on your device.

Here's how to add a Google Account on your device:


1. Under "Accounts", touch **+ Add account**.
2. Select  Google.
3. Choose **Existing** (if you want to add an account you already have) or **New** (if you want to create a new one).
4. Follow the instructions to add your account.

Download the MyAir4 App from the  Google Play Store.


1. Open the  Google Play Store app.
2. Search for "MyAir 4"



a) Touch the MyAir4 app.




b) Touch **INSTALL** (It's Free).



c) Touch **Accept** after reviewing the app's permissions

Network Troubleshooting

Assistance for the Homeowner's IT professional:

1. Check the Wi-Fi router is turned ON.
2. Check that the smart phone / tablet device is connected to the Wi-Fi (not using "Mobile Data/3g/4g").
3. Check that the MyAir4 system is connected to the same Wi-Fi network.
 - a. First, exit the MyAir4 app. To do this, press the SETTINGS button then select CLOSE APP.
 - b. Press RUN OTHER APPS & you will then see the main Android home screen.
 - c. Press the apps icon on the right. 
 - d. Then press the settings icon.
 - e. At the top of the list on the right check that it is connected to the same network as the smart phone / tablet devices.
4. For further info see the troubleshooting table on the following page.

Issue	Possible Cause	Possible Solution
1. MyAir4 App does not connect to MyAir4 system.	MyAir4 is not connected to the home Wi-Fi network.	Check connection on Android settings page as per instructions on previous page.
	Home Wi-Fi is not set to DHCP.	Homeowner contact your IT professional to use DHCP home Wi-Fi settings.
2. Device is out of range of the home Wi-Fi system / cannot connect.	Your Device may not connect to your Wi-Fi network from all rooms and all parts of your home. Test: You can turn off cellular/mobile data and test your Wi-Fi network by opening a new web browsing session	Move the device into the Wi-Fi range.
	Device is not connected to the Wi-Fi network	Connect your device to your network using instructions that came with your Device
3. Belkin Router		Some Belkin routers require you to plug the Belkin WAN port into your home wired network before they will issue a DHCP IP addresses

How to reset your Wi-Fi control

1. Turn off the power to your home Wi-Fi router.
2. Turn off the power to your air-conditioning system. One way to do this is at the isolating switch, usually located on the wall near your outdoor unit.
3. Turn on the power to your home Wi-Fi router.
4. Turn on the power to your air-conditioning system
5. If connections are successful then the DHCP enabled Wi-Fi device will give the MyAir4 a DHCP IP address and will show that the system is connected via the Android touch screen controller's Wi-Fi settings page.

Further Information

1. The MyAir4 App does not work via the internet. You need to be within your Wi-Fi range, and connected to your home Wi-Fi network.
2. You do not need to have a home internet connection to use the MyAir4 App – the App uses Wi-Fi only to connect to your air conditioner.

Troubleshooting

If you are experiencing problems, with the operation of your touch screen, perhaps due to browsing or installation of apps, you may factory reset the tablet by pressing the power button to wake the screen, then pressing the reset button on the top left of the touch screen panel with a paper clip or similar. This will remove any apps that have been installed, and reset the tablet to the condition at installation.

If you are experiencing problems with the operation of the system, you may reset the system using the isolator switch located next to your air-conditioner's outdoor unit. Turn the Isolator switch off, then try pressing the button to wake the touch screen. The touch screen should be inoperable. After a 5 minute delay, turn the isolator back on and allow approximately 3 minutes for the system to initialise.

- If air volume control is applicable, then increase all zones to 100%.
- If you have wireless wall sensors ensure the batteries aren't low, if the batteries are low a warning will be displayed on your HOME screen.
- Check for any fault codes that may be displayed in the SETTINGS screen, if a fault code is present contact your dealer and advise them of the fault code being displayed.
- If you are still experiencing difficulties, contact your dealer for further assistance.

Service Records

DATE	SERVICED BY	BATTERIES CHANGED	COMMENTS
		YES / NO	
		YES/ NO	
		YES / NO	
		YES / NO	
		YES / NO	
		YES / NO	
		YES / NO	